

**MAN B&W 6 L 28/32 Engine and Spare Parts Sourced from Ship Beached here  
for demolition. For Repairing and Spare Parts Supply Please contact us –  
info@steelmarineservice.com**

Piston ring №1	60601-51-1214
Piston ring №2	60601-51-1303
Piston ring №3	60601-51-1492
Oil scraper ring	60601-51-1581
Connecting rod screw	60601-51-0968
Connecting rod bearing MDO	60601-51-1670
Connecting rod bush	60601-51-0780
Sealing ring	61101-42-2554
Sealing ring for cylinder. cover/cylinder. liner	60610-50-0136
Sealing ring	60610-50-0405
Valve seat ring, inlet	60501-52-3689
Valve seat ring, exhaust	60501-52-3590
Cooling water connection	60501-52-4579
Valve guide	60501-52-2422
Nut	60501-52-1443
Nut	60501-52-0197
Packing for top guard	60510-51-1344
Packing for top cover	60510-51-1166
Inlet Valve	60502-50-3103
Exhaust Valve	60502-52-3292
Valve cone piece	60502-52-1056
Spring	60502-52-2679
Inlet and exhaust valve spring	60502-52-1234
Inlet and exhaust valve spring	60502-52-1323
Valve rotator	60502-52-2946
Axial bearing	60502-52-3381
Gasket	60508-22-0279
Gasket	60508-22-0724
Gasket	60508-22-0813
Camshaft bearing	60705-40-0359
Gasket	60705-40-3207
Lock Screw	60705-40-3396
Camshaft bearing «Aft»	60705-40-0171
Camshaft «Fore»	60705-40-1794
Camshaft «Fore»	60705-40-0260
Housing for roller guides	60801-51-2291
Supporting ring	60801-51-1589
Roller guides, complete	60801-51-1034
Roller guides, complete	60801-51-2924
Spring retainer	60801-51-1856
Thrust disc	60801-51-2479
Vibration damper, 6 Cylinder	61002-31-0150

Handle	61106-41-2787
Gasket	61202-41-1682
Gasket	61202-41-1593
Sealing ring	61202-41-0881
Sealing ring	61202-41-1048
Gasket	61202-41-1860
Screw	61202-41-2116
Nut	61202-41-1959
Compensator	61203-42-1106
Gasket	61203-42-1295
Starting valve complete	61302-21-0107
Starting air distributor	61303-30-0190
Starting valve complete	61304-50-1193
Banjo coupling	61411-42-1947
Banjo coupling	61411-42-2104
Straight connection	61411-42-1303
Branch pipe for sealing oil, intel	61411-42-2293
Male stud elbow coupling	61411-42-0324
Elbow bulk head coupling MDO	61411-42-1769
Non- return valve	61411-42-0235
Banjo coupling	61411-42-1214
Coupling	61412-31-2084
Fuel oil primary pump, complete, CW	61412-31-3518
High pressure fuel pipe complete	61413-50-1163
Gasket	61415-26-1012
Strainer for item 0294	61502-23-0472

We are Steel Marine Service, and we are experts in repairing MAN B&W L 28/32H engines. We also supply genuine spare parts and stock them for urgent requirements. All the spare parts we offer are sourced from ships that have been beached here for demolition. We have our own logistics team that covers sea and air freight, and we can deliver parts and machinery directly on board, to the nearest airport, or to your door.

**Steel Marine Service.**

Mob: +91 99794 40977 | Email: [info@steelmarineservice.com](mailto:info@steelmarineservice.com)