

**SULZER RTA 52 Ship Main Engine Spares Available for Sale, Obtained from Ship Beached here for demolition. Contact us - [info@steelmarineservice.com](mailto:info@steelmarineservice.com)**

<b>Spares</b>	<b>Part Number</b>
Starting air valve, complete (Z 27401 - Z 27431)	Z 27400
Ring for starting air valve	Z 27406
Valve spindle with nut for starting air valve	Z 27408
Piston for starting air valve	Z 27409
Spindle guide for starting air valve	Z 27413
Compression spring for starting air valve	Z 27418
Piston ring for starting air valve	Z 27424
Piston ring for starting air valve	Z 27425
Piston ring for starting air valve	Z 27426
O-ring for housing Z 27401	Z 27429
Joint ring for valve seat Z 27414	Z 27431
Hydraulic piping for exhaust valve, complete	Z 84400
O-ring for housing Z 84458 and for joint rings Z 84459 and Z 84460	Z 84491
O-ring for guide pipe Z 84465	Z 84493
Cylindrical screw for hydraulic piping	Z 84486
Cylindrical screw for hydraulic piping	Z 84485
Joint disc for hydraulic piping	Z 84461
Housing for hydraulic piping	Z 84458
Joint ring for hydraulic piping	Z 84459
O-ring for guide pipe Z 84465	Z 84493
Joint ring for hydraulic piping	Z 84460
Cylindrical screw for hydraulic piping	Z 84487
Fuel pressure pipe with heating and insulation, complete	Z 87001
Fuel pressure pipe with heating and insulation, complete	Z 87007
Fuel pressure pipe with heating and insulation, complete	Z 87020
Fuel pressure pipe with heating and insulation, complete	Z 87026
Fuel pressure pipe with heating and insulation, complete	Z 87033
Fuel pressure pipe for fuel injection valve	Z 87048
Fuel pressure pipe for fuel injection valve	Z 87055
Fuel pressure pipe with heating pipe and insulation, complete	Z 43013
Control valve, complete	Z 43140
O-ring for cover Z 43121	Z 43126

Roller for control valve	Z 43143
3/2 way valve for starting control valve	Z 43166
O-ring for starting cut-off valve Z 43120	Z 43171
O-ring for control valve Z 43140	Z 43172
Starting control valve, complete	Z 43100
Starting cut-off valve, complete	Z 43120
Piston seal ring for axial slide valve Z 45105	Z 45145
Rod seal ring for bush Z 45105	Z 45146
Rod seal ring for brackets Z 45106 and Z 45112	Z 45147
3/2 way valve for reversing valve	Z 45126
3/2 way valve for reversing valve	Z 45128
O-ring for reversing valve	Z 45148
O-Ring for Z 17048	Z 17046
Joint for HOERBIGER- relief valve Z17048	Z 17085
Joint for inspection cover Z 15201	Z 15205
Joint for cover Z 17001	Z 17004
Joint for cover Z 17006	Z 17010
Joint for cover Z 17014	Z 17021
Joint for crankcase door	Z 17115
Set studs and nut one cyl. cover (Z 27106, Z 27107, Z 27108, Z 27118, Z 27199)	Z 27160
Round rubber ring seamless for cylinder valve	Z 27116
Set O-ring, joints, piston ring and locking plate ( Z 27530, Z 27535, Z 27541, Z 27542, Z 27548, Z 27555 and 27557)	Z 27660
Set O-ring, joints, piston ring and locking plate ( Z 27550, Z 27510, Z 27513, Z 27521, Z 27524, Z 27550, Z 27551, Z 27553, Z 27554, Z 27556, Z 27558, Z 27565)	Z 27670
Piston for valve drive Z 27525	Z 27532
Valve seat for valve cage Z 27501	Z 27509
Bush for valve drive Z 27525	Z 27531
Piston for exhaust valve	Z 27516
Split groove valve collet for piston Z 27516	Z 27517
Thrust flange for piston Z 27516	Z 27518
Guide bush for valve cage Z 27501	Z 27511
Set parts for relief valve (Z 27707, Z 27709)	Z 27750

Set of packings for the relief valves (Z 27710, Z 27712)	Z 27760
Set tap washers and O-rings for piston (Z 34014, Z 34024, Z 34025, Z 34027, Z 34028, Z 34030)	Z 34260
Circulation valve for fuel injection valve (Z 27216 - Z 27220)	Z 27215
O- ring for circulation valve Z 27215	Z 27226
O- ring for spring tensioner Z 27212	Z 27225
Nozzle with needle for fuel injection valve (two piece nozzle)	Z 27242
O-ring for nozzle holder Z 27201	Z 27224
Atomizer for fuel injection valve(two piece nozzle)	Z 27244
Spindle for fuel injection valve	Z 27210
Spring carrier for fuel injection valve	Z 27211
Compression spring for fuel injection valve	Z 27221
Safety cut out device, complete	Z 53200
3/2- Way solenoid for safety cut out device	Z 53210
O- ring for valve holder Z 53207	Z 53230
O- ring for housing Z 53201	Z 53231
O- ring for cover Z 53204	Z 53232
O- ring for 3/2- Way solenoid Z 53210	Z 53233
Rod joint ring for housing Z 53201 and for guide bush Z 53212	Z 53229
Piston joint ring for piston Z 53203	Z 53228
Stud coupling for fuel injection pump	Z 55852
Emptying screw for fuel injection pump	Z 55853
Screw plug for Z 55185	Z 55834
Screw plug for Z 55185	Z 55855
Joint ring for stud coupling Z 55852	Z 55856
Joint ring for emptying screw Z 55853	Z 55857
Joint ring for screw plug Z 55854	Z 55858
Connection piece for fuel injection pump	Z 55850
Relief valve, complete for fuel injection pump (Z 55809 – Z 55819)	Z 55808
Plunger with bush and spring carrier, complete for fuel injection pump	Z 55260
Spill valve with seat, complete for fuel injection pump	Z 55801
Suction or delivery valve with seat, complete for fuel injection pump	Z 55805
Compression spring for suction and spill valves	Z 55831

Pressure bush for suction and spill valves	Z 55821
Pin for suction and spill valves	Z 55836
Pressure bush for delivery valve	Z 55822
Compression spring for delivery valves	Z 55832
Cover for valves	Z 55830
Cover for valves	Z 55835
Stagnation pressure control valve, complete, for fuel injection pump	Z 55882
Push rod with guide bush and spring, complete for suction and spill valve control	Z 55824
Compression spring for push rod Z 55824	Z 55828
Compression spring for plunger Z 55260	Z 55562
Nipple for guide bush for plunger	Z 55462
Roller guide for fuel pump, complete (Z 55421 – Z 55432)	Z 55420
Bearing with cover for eccentric shaft	Z 55450
Bearing with cover for eccentric shaft	Z 55456
O – ring for rotational safety stud Z 55555	Z 55557
Roller for roller guides Z 55420 and Z 55435	Z 55425
Bush for roller guides Z 55420 and Z 55435	Z 55428
Push rod, complete	Z 55463
Control lever for suction valve	Z 55536
Control lever for spill valve	Z 55538
Compression spring for roller quid Z 55420	Z 55563
Roller quid for actuator pump, complete (Z 55425 – Z 55432, and Z 55436)	Z 55435
Piston ring with gas tight snap for piston Z 55509	Z 55510
Distance ring for actuator housing	Z 55511
Fitted two-way valve	Z 55514
Relief valve for actuator piston	Z 55516
Locking ring for bush Z 55508	Z 55522
O- ring for actuator housing Z 55500	Z 55570
Lubricating quill with accumulator for cylinder lubrication in complete (Z 21501, Z 21502, Z 21515, Z 21522, Z 21524)	Z 21500
Non-return valve, complete for accumulator cylinder lubrication (Z 21516-Z 21519)	Z 21515

Accumulator on lubricating quill, complete (Z 21503 - Z 21508)	Z 21502
Compression spring for non-return valve	Z 21519
Ball for non-return valve	Z 21518
Filling pin for lubricating quill	Z 21517
Housing for non-return valve Z 21515	Z 21516
Compression spring for accumulator	Z 21508
Piston for accumulator	Z 21506
Diaphragm for accumulator	Z 21505
Lubricating quill	Z 21501